
For IU-1000F Maintenance Kit Users

This guide introduces the maintenance kit.

Flushing pad 	This is a replacement part for the maintenance station flush receiver. Replace the flushing pad when the amount of collected ink is such that the ink is 3 mm or higher above the upper surface of the flushing pad. For the replacement method, see "Replacing the Flushing Pad" under "Requests for Daily Care and Maintenance."
Carriage filters 	These replacement parts are located in the left and right UV lamps of the carriage. Replace them once every 3 months. For the replacement method, see "Replacing the Carriage Filter" under "Requests for Daily Care and Maintenance."

© 2020 Roland DG Corporation

July 2020 M0DW7030
R1-200727 1000023036
M0DW7030