




Special Color Ink Guide

Target Models : LEC-330/540,LEJ-640,LEF-12i/200/300

Chapter 1 Getting Ready.....	3
Chapter 2 Printing.....	15
Chapter 3 Advanced.....	49

What to Check First

Check the version of VersaWorks installed on your PC and refer to the instruction manual that matches your specifications.

VersaWorks LOGO	Manual
 <p><i>Roland VersaWorks</i> RIP & PRINT MANAGEMENT SOFTWARE</p>	This document
 <p><i>Roland VersaWorks Dual</i> RIP & PRINT MANAGEMENT SOFTWARE</p>	
 <p>VersaWorks 6</p>	https://webmanual.rolanddg.com/VersaWorks6

Thank you very much for purchasing this product.

- To ensure correct and safe usage with a full understanding of this product's performance, please be sure to read through this manual completely and store it in a safe location.
- Unauthorized copying or transferal, in whole or in part, of this manual is prohibited.
- The specifications of this product and the contents of this manual are subject to change without notice.
- The manual and the product have been prepared and tested as much as possible. If you find any misprints or errors, please inform us.
- Roland DG Corp. assumes no responsibility for any direct or indirect loss or damage that may occur through use of this product, regardless of any failure to perform on the part of this product.
- Roland DG Corp. assumes no responsibility for any direct or indirect loss or damage that may occur with respect to any article made using this product.

Contents

Contents	1
Chapter 1 Getting Ready	3
What This Document Assumes and Related Manuals	4
What This Document Assumes	4
Related Manuals	4
Features of and Printing Methods for Special Color Inks	5
Features of Special Color Inks	5
Printing Method Using White Ink	5
Printing Method Using Gloss Ink	6
Printing Method Using Primer	6
Important Points to Know Before Performing Operations	7
Important: Characteristics of Inks and Important Notes	7
Important Notes in Using Transparent Media	7
Degreasing the Print Surface	8
Creating Printing Data	9
Basic Approach for Creating Printing Data	9
Creating Printing Data Using a Spot Color for Special Colors	9
Chapter 2 Printing	15
Introduction	16
Before You Start Printing	16
Media	16
Print Modes	16
Printing Using White Ink	18
Printing Only with White Ink	18
Printing with White and CMYK Colors in a Single Pass	20
Printing Using Gloss Ink	24
Gloss-finish Printing (White or CMYK Colors > Gloss)	24
Matte-finish Printing (White or CMYK Colors > Gloss)	27
Matte-finish Printing (Single-pass Printing Using CMYK Color and Gloss Inks)	30
Embossed-finish Printing (White or CMYK Colors > Gloss)	32
Printing Only with Gloss Ink	39
Printing Using Primer	42
Printing Only with Primer	42
Printing with Primer and CMYK Colors or White in a Single Pass	44
Starting the Print Operation	46
Starting the Print Operation	46
Chapter 3 Advanced	49
Performing Texture Printing	50
What is Texture Printing?	50
Checking the Pattern of Texture Printing	50
Printing Texture Data	52
More Advanced Printing Settings	55
Making Printing Settings for Each Job	55
Composing CMYK Data and White/Gloss Data with VersaWorks	56
Generating Special Color Plates	58
Correcting the Position of Special Color Plates	60
Correcting the Size of Special Color Plates	62

This document is the user's manual common to the VersaUV Series. Most of the figures in this manual depict the LEC-540.

In this guide, excluding the case where "Roland VersaWorks" or "Roland VersaWorks Dual" is shown on the computer screen, "Roland VersaWorks" and "Roland VersaWorks Dual" are written as "VersaWorks."

Copyrights and property of this software and this manual belong to Roland DG Corp. No part of this software or publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopy, recording or otherwise, without the prior written permission of the publisher.

Roland VersaWorks and Roland VersaWorks Dual are registered trademarks of Roland DG Corp.

Windows® is a registered trademark or trademark of Microsoft® Corporation in the United States and/or other countries.

Pentium® is a registered trademark of Intel Corporation in the United States.

Macintosh is a registered trademark of Apple Inc.

Adobe, PostScript, PostScript 3, and Illustrator are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries. ©2007 Adobe Systems Incorporated. All rights reserved.

Other company names and product names are trademarks or registered trademarks of their respective holders.

Chapter 1 Getting Ready

What This Document Assumes and Related Manuals.....	4
What This Document Assumes	4
Related Manuals.....	4
Features of and Printing Methods for Special Color Inks.....	5
Features of Special Color Inks	5
Printing Method Using White Ink	5
Printing Method Using Gloss Ink	6
Printing Method Using Primer.....	6
Important Points to Know Before Performing Operations	7
Important: Characteristics of Inks and Important Notes	7
Important Notes in Using Transparent Media	7
Degreasing the Print Surface	8
Creating Printing Data.....	9
Basic Approach for Creating Printing Data	9
Creating Printing Data Using a Spot Color for Special Colors.....	9

What This Document Assumes and Related Manuals

1

Getting Ready

What This Document Assumes

- This guide is for use with both Roland VersaWorks and Roland VersaWorks Dual.
- “Roland VersaWorks” and “Roland VersaWorks Dual” are both written as “VersaWorks” in this guide.
- Before performing any operations described in this guide, make sure that all the following preparations are complete.
 - Hardware setup, such as the assembly and installation of the printer.
 - Software setup, such as installing VersaWorks on your computer and connecting the computer to the printer.
 - Learning the operation of the printer (Refer to the manual included with the printer for more on the operation of the printer.)
- This guide is for use with the following printers. Ignore parts of this manual regarding inks not being used.
 - Printers equipped with white ink, gloss ink, and primer
 - Printers equipped with white ink and gloss ink
 - Printers equipped with white ink and primer
 - Printers equipped with white ink
 - Printers equipped with gloss ink

Related Manuals

Refer to the following manuals for information on basic and advanced VersaWorks operations.

Help

This manual is included with the software. Information on all software functions, from instructions for basic usage of software to detailed instructions for settings, is provided in this guide.

Features of Special Color Inks

White

The special white ink used in this printer achieves high density and concealment, and is capable of providing attractive results even when white and CMYK colors are overprinted. This ink is suited to printing on transparent media, and can be used it to create items for shop interiors and displays, PET bottles and other packages, decals, and more.

Gloss

The special gloss ink used in this printer is colorless and transparent, and can impart a glossy feel to the printed item, as well as enhance weatherability and robustness . Also, depending on the printing settings, you can even deliberately eliminate glossiness and produce a matte finish, or perform fill overprinting using gloss ink to raise the printed surface and create an embossed finish.

- * Glossiness, weatherability, and robustness may vary depending on the media used, the environment, and other printing conditions.

Primer

The primer is a colorless and transparent coating agent used as an ink base. By using the primer as a base, you can print on glass or other materials on which UV ink cannot be applied.

- * The primer may not be fully efficient on some materials. Be sure to perform test printing to check the effect.

Printing Method Using White Ink

Printing White Only

You can also perform printing using white ink only. To display the side opposite the printed surface, you can take such action as printing a mirror image of the artwork.

- ☞ P. 18, "Printing Only with White Ink"

Printing using white and CMYK ink

Print the area using white ink and the area using CMYK color inks simultaneously, in a single pass. Printing the areas simultaneously eliminates displacement during media feed, making stable, highly intricate printing possible. When you're printing on a transparent film, you can create results intended to be viewed from the back (the side opposite the printed surface) by reversing the image or changing the sequence in which white and CMYK colors are printed.

- ☞ P. 20, "Printing with White and CMYK Colors in a Single Pass"

Printing Method Using Gloss Ink

Gloss-finish Printing

This printing method imparts a glossy finish to the printed item. Forming a coating of gloss ink imparts a glossy finish and can also achieve high weatherability and robustness.

The output printed using white or CMYK color inks is pulled back once and then is overprinted with gloss ink.

☞ P. 24, "Gloss-finish Printing (White or CMYK Colors > Gloss)"

Printing using only gloss ink is also possible.

☞ P. 39, "Printing Only with Gloss Ink"

Matte-finish Printing

This printing method eliminates glossiness and produces a restful matte finish. This perform fill overprinting of white and CMYK colors with gloss ink, which makes it possible to produce results where glossiness is suppressed while weatherability and robustness are enhanced.

When white ink is used, the output printed using white or CMYK color inks is pulled back once and then is overprinted with gloss ink.

☞ P. 27, "Matte-finish Printing (White or CMYK Colors > Gloss)"

When white ink is not used, printing can be done with CMYK color inks and gloss ink simultaneously without the pulling back process.

☞ P. 30, "Matte-finish Printing (Single-pass Printing Using CMYK Color and Gloss Inks)"

Printing using only gloss ink is also possible.

☞ P. 39, "Printing Only with Gloss Ink"

Embossed-finish Printing

This printing method can produce items that have a three-dimensional feel by performing fill overprinting of the item using gloss ink. You determine the height to which the printed surface is raised by setting the number of fill-overprint passes in VersaWorks. After performing fill-overprinting by this specified number of passes, the item is overprinted one last time using gloss ink to produce a gloss finish.

The output printed using white or CMYK color inks is pulled back once and then is overprinted with gloss ink.

☞ P. 32, "Embossed-finish Printing (White or CMYK Colors > Gloss)"

Printing using only gloss ink is also possible.

☞ P. 39, "Printing Only with Gloss Ink"

Printing Method Using Primer

Printing with Primer Only

Perform printing by using primer only. After that, perform printing by using other colors.

☞ P. 42, "Printing Only with Primer"

Printing with Primer and Other Inks Simultaneously

Perform printing by using primer and other colors simultaneously while using the primer as a base.

☞ P. 44, "Printing with Primer and CMYK Colors or White in a Single Pass"

Important Points to Know Before Performing Operations

1

Getting Ready

Important: Characteristics of Inks and Important Notes

The usage and handling of white ink involves some important considerations that do not apply to ink of other colors. Be sure to familiarize yourself with the characteristics of the inks before you use them.

White ink settles and separates.

If they are allowed to stand, the precipitates in the inks may solidify and cause clogging of the print heads or other malfunctions. Be sure to observe the cautions in this manual.

Maintenance Must be Performed.

- Always keep the main power switched on. If the main power is switched off, the automatic maintenance function stops working, and may result in malfunction.
- We recommend operating the printer at least once a week.
- If the printer is left unused for a long period of time, ink precipitation may occur, causing unstable ink discharge, which may result in dot drop-out, etc. In such cases, the precipitated and solidified ink needs to be discharged. Refer to the user's manual of the printer you are using to implement proper cleaning.
- If cleaning fails to resolve issues such as dot drop-out, contact your authorized Roland DG Corp. dealer.

Important Notes in Using Transparent Media

* The following is not applicable to the LEF Series.

Loading Transparent Media

- Set the [EDGE DETECTION] menu item to "DISABLE." Transparent media cannot be loaded unless this setting is made.
- Ensure a margin of at least 75 mm (2.95 in.) from the leading edge of the media to the printing- or cutting-start location.

Important Notes on the Amount of Media Remaining

- When you use transparent media, the presence of media cannot be detected. In such cases, printing operation does not stop when the media runs out, and there is a chance that the platen or the like may become soiled by ink or that ink may get inside and damage the machine.
- If media runs out while printing is in progress, immediately stop printing.

Using the Middle Pinch Rollers

The middle pinch rollers will leave slight traces of pressing on the media, and on transparent media this damage can be very noticeable. Also, the middle pinch rollers will smudge the printed surface when transparent media is pulled back after printing. When using transparent media, secure the media in place using only two pinch rollers on the right and the left. However, some types of media may float partially, causing adverse effects on printing, feeding, and/or cutting. Check the media before use.

Automatic Crop-Mark Detection

Automatic crop-mark detection may not be possible for some media, such as transparent media. In such cases, perform alignment manually.

Degreasing the Print Surface

When primer is used, degreasing the print surface before printing is effective to improve ink adhesion. For inks other than primer, degreasing the print surface before printing may also be effective to improve ink adhesion.

Creating Printing Data

Basic Approach for Creating Printing Data

Using a Spot Color for Special Colors

Select a spot color for special colors from the exclusive swatch library and apply the spot color on the printing data.

- **White: RDG_WHITE**
- **Gloss: RDG_GLOSS**
- **Primer: RDG_PRIMER** (Usable with VersaWorks Dual only)
☞ P. 9, "Creating Printing Data Using a Spot Color for Special Colors"

Generating Special Color Plates with VersaWorks Dual

Even with printing data in which a spot color for special colors is not used (printing data in which only CMYK colors is used), you can use the function of VersaWorks Dual to generate special color plates (white, gloss, and primer).

- * This function is available with VersaWoks Dual only. It cannot be used with VersaWoks.
☞ P. 58, "Generating Special Color Plates"

Creating Printing Data Using a Spot Color for Special Colors

Create the data for printing using the white ink or gloss ink.

The description in this section uses Adobe Illustrator CS6. For detailed information on drawing methods and how to work with palettes, refer to the documentation or online help for Adobe Illustrator CS6. If you are using another version of Adobe Illustrator, operations may be somewhat different from those explained here.

1. Open the exclusive swatch library and color library.

1 Open the dialog box to use in selecting the library.


① Open the swatch palette menu.

The swatch palette is displayed by going to the menu and selecting [Window], then [Swatches].

② Click [Open Swatch Library].


③ Click [Other Library].

The "Open" (or "Select Library") dialog box appears.



2 Open the exclusive swatch library.

- ① **Open the folders in the order of [Computer] → [OS (C:)] → [Program Files] ([Program Files (x86)] for 64-bit OS) → [Roland VersaWorks] (or [Roland VersaWorks Dual]) → [Swatch] → [Illustrator].**
- ② **Select “Roland VersaWorks.ai.”**
Depending on the settings of your computer, the extension “.ai” might not be shown.
- ③ **Click [Open].**
The swatch library containing “RDG_WHITE,” “RDG_GLOSS,” and “RDG_PRIMER” is displayed.



MEMO

By saving the “.ai” file selected in step **2** into the folder below, you can register each swatch library to the Adobe Illustrator library. Once the registration is performed, you can open the library directly from the swatch palette menu, eliminating the need to search the file every time you start Adobe Illustrator.

C:\Program Files\Adobe\Adobe Illustrator CS6\Presets\(\language abbreviation)\Swatches

- * "C" is the name of your computer's local disk.
- * For 64-bit OS, select [Program Files (x86)] instead of [Program Files].
- * The language abbreviation differs depending on the language used.
- * Depending on the version of Illustrator used, “\Preset\Swatch” may be used instead of “\Presets\(\language abbreviation)\Swatch.”

2. Create the illustration, and specify the spot color that matches the color you want to print.


1 Create the illustration.

Be sure to draw the illustration in the CMYK mode.

2 Specify each spot color that matches the color you want to print.

Desired ink or color	Spot color name
White ink	RDG_WHITE
Gloss ink	RDG_GLOSS
Primer	RDG_PRIMER

* "RDG_PRIMER" is usable with VersaWorks Dual only.



3. Create the PS (PostScript) file.

* When using VersaWorks Dual, saving the file as a PDF file rather than a PS file is recommended.


1 Select [Roland VWD] or [Roland VW].

1 Select [Print] from the [File] menu.


2 Select [Roland VW].

When a nickname is set, or when more than one printer is connected, select "Roland VW_(the nickname of the printer used for output)."


3 Click [Setup].




4 Click [Continue].



- 2 Set the page size of the output data.
 - 1 Turn on the [Print to file] option.
 - 2 Click [Preferences].
 - 3 Click [Advanced] in the [Layout] tab.





- 4 Click the down arrow to the right of the [Paper Size] box, and then click [PostScript Custom Page Size] from the list that appears.
- 5 For "Custom Page Size Definition," enter the values in the "Width" and "Height" fields. Enter values for the same size as the illustration you created in step 2.



- 3 Click [OK] three times to close the "PostScript Custom Page Size Definition," "Roland VersaWorks Advanced Options," and "Printing Preferences" dialog boxes. The "Print" dialog box returns.

4 Output the data as a file.

- 1 Click [Print].
- 2 Click [Print].




3 Specify the destination and file name.

Example: "C:/white-gloss_print" for the folder to save to, and "white-gloss_print.ps" as the file name

4 Click [Save].

The image is saved in the specified folder as a PS file.



Chapter 2 Printing

Introduction	16
Before You Start Printing	16
Media.....	16
Print Modes	16
Printing Using White Ink.....	18
Printing Only with White Ink.....	18
Printing with White and CMYK Colors in a Single Pass	20
Printing Using Gloss Ink.....	24
Gloss-finish Printing (White or CMYK Colors > Gloss).....	24
Matte-finish Printing (White or CMYK Colors > Gloss).....	27
Matte-finish Printing (Single-pass Printing Using CMYK Color and Gloss Inks)	30
Embossed-finish Printing (White or CMYK Colors > Gloss).....	32
Printing Only with Gloss Ink.....	39
Printing Using Primer	42
Printing Only with Primer	42
Printing with Primer and CMYK Colors or White in a Single Pass	44
Starting the Print Operation	46
Starting the Print Operation	46

Before You Start Printing

- Remove just the white ink cartridge, shake it 50 times (about 15 seconds), and then reinsert this cartridge.
- The ink cartridges other than white do not need to be shaken before every operation, but be sure to shake them when installing new ones.

If ink components precipitate, it will not be possible to print with correct colors. So that the ink mixes well, shake the ink cartridge horizontally with a stroke length of around 5 cm (2 in.) from each end of the ink cartridge. The components in the white ink have a tendency to precipitate. Each day, before starting the day's operations, be sure to carry out the above steps. Allowing the ink to stand without carrying out these steps can cause the settled material to harden, resulting in malfunction or other problems.

Media

You can select media from different types of paper in order to meet your needs. Before selecting media, be sure to perform trial printing to check whether satisfactory output quality is obtained.

Print Modes

Set the print mode based on the type of ink and printing method.

Print mode	Color of ink used and printing method	Page
White	Print only with white ink.	P. 18
White -> CMYK	Print white and CMYK color data in a single pass. The white ink is overprinted by the CMYK color inks.	P. 20
CMYK -> White	Print white and CMYK color data in a single pass. The CMYK color inks are overprinted by the white ink.	P. 20
GlossVarnish	Carry out gloss-finish printing using gloss ink. After performing printing using white and CMYK color data, this method pulls back the media, then performs fill overprinting using gloss ink. Printing using only gloss ink is also possible. (*)	P. 24 (*)P. 39
MatteVarnish	Carry out matte-finish printing using gloss ink. After performing printing using white and CMYK color data, this method pulls back the media, then performs fill overprinting using gloss ink. Printing using only gloss ink is also possible. (*)	P. 27 (*)P. 39
CMYK -> MatteVarnish	Carry out matte-finish printing using gloss ink. Printing of CMYK color data and gloss ink data is performed in a single pass, but the sequence is such that the CMYK color inks are overprinted by the gloss ink.	P. 30

Print mode	Color of ink used and printing method	Page
Embossing	Carry out embossed-finish printing using gloss ink. After performing printing using white and CMYK color data, this method pulls back the media, then performs fill overprinting using gloss ink. Printing using only gloss ink is also possible. (*)	P. 32 (*)P. 39
Primer1	Print only with primer. The texture of the finish and ink adhesion are different between Primer 1 and Primer 2. You can also perform printing using Primer 1 and Primer 2 in turns. Overlaying Primer 1 and Primer 2 may result in different effects in the texture or adhesion from the case where they are used individually for printing. The texture and adhesion may vary depending on the media to be used. Select an appropriate type according to their properties.	P. 42
Primer2		
Primer -> CMYK	Print primer and CMYK color data in a single pass. The primer is overprinted by the CMYK color inks.	P. 44
Primer -> White	Print primer and white data in a single pass. The primer is overprinted by the white ink.	P. 44

Printing Using White Ink

Printing Only with White Ink

This section describes how to perform printing only with the white ink.


Procedure

1 Create data for printing.

☞ P. 9, "Creating Printing Data"


2 Double-click .

The "Queue A Properties" window appears.




3 Select the media type, print quality, and print mode.

1 Click .



2 Select a [Media Type].

Generic	This is the basic setting when white ink is used.
Generic High-opacity White	This outputs white of higher opacity than "Generic." Depending on the ink type of your printer, this option may be disabled.
Generic Distance	This can be selected when you use the LEF-12i, LEF-200, or LEF-300. This setting is suitable when you print on media whose print surface is uneven.




③ Select a [Print Quality].

* The items displayed for [Print Quality] will vary depending on the [Media Type] selected in step 2.

④ For [Mode], select [White].

* The items displayed for [Mode] will vary depending on the model used.


* The name for [Mode] may have a suffix such as "(v)" or "10p."




④ Set the printer operation.

* This setting is unnecessary for the LEF series.

① Click .



② In [Operation Mode], select "Print Only."




③ Turn off the [Return to Origin After Print] option.




MEMO: When you want to display the side opposite the printed surface by using clear film

① Click .



② Turn on the [Mirror] option.

When the printing data with mirror image is prepared beforehand, you do not need to turn on this option.



⑤ Click [OK] to close the "Queue A Properties" window.

This is the end of the print job setting. To start printing, proceed to P. 46, "Starting the Print Operation".

- * Only the settings necessary for the use of the white ink are described in this section. For other settings, refer to the online help provided for VersaWorks.

Printing with White and CMYK Colors in a Single Pass

This section describes how to perform printing with white ink and CMYK color inks. Deciding which ink between white and CMYK you want to use for the base is an important point in determining the print job settings here.


Procedure

① Create data for printing.

⇨ P. 9, "Creating Printing Data"


② Double-click .

The "Queue A Properties" window appears.




3 Select the media type, print quality, and print mode.

① Click .



② Select a [Media Type].

Generic	This is the basic setting when white ink is used.
Generic High-opacity White	This outputs white of higher opacity than "Generic." Depending on the ink type of your printer, this option may be disabled.
Generic Distance	This can be selected when you use the LEF-12i, LEF-200, or LEF-300. This setting is suitable when you print on media whose print surface is uneven.



③ Select a [Print Quality].

* The items displayed for [Print Quality] will vary depending on the [Media Type] selected in step 2.

④ For [Mode], select the print mode.

White -> CMYK	Inks are overprinted in the sequence of white and then CMYK.
CMYK -> White	Inks are overprinted in the sequence of CMYK and then white.

* These modes may be disabled depending on the print quality selected in step 3.

* The items displayed for [Mode] will vary depending on the model used.

* The name for [Mode] may have a suffix such as "(v)" or "10p."






Image of overprinting in the sequence of white and then CMYK



- * The white data and the CMYK color data are actually printed simultaneously, but they are shown here as separate layers in order to indicate the printing sequence.

Image of overprinting in the sequence of CMYK and then white




- * The white data and the CMYK color data are actually printed simultaneously, but they are shown here as separate layers in order to indicate the printing sequence.


4 Set the printer operation.

- * This setting is unnecessary for the LEF series.


① Click .



- ② In [Operation Mode], select “Print Only.”



- ③ Turn off the [Return to Origin After Print] option.



MEMO

See P. 20, "MEMO: When you want to display the side opposite the printed surface by using clear film" when you want to display the side opposite the printed surface by using clear film.

- ⑤ Click [OK] to close the “Queue A Properties” window.

This is the end of the print job setting. To start printing, proceed to P. 46, "Starting the Print Operation".

- * Only the settings necessary for the use of the white ink are described in this section. For other settings, refer to the online help provided for VersaWorks.

Printing Using Gloss Ink

Gloss-finish Printing (White or CMYK Colors > Gloss)

This section describes the printing method that produces a glossy finish on the printed item. After performing printing using white and CMYK color data, this method pulls back the media, then performs fill overprinting using gloss ink. This means that the setting must be made to pull back the media after printing the white and CMYK color data.

* For the LEF series, there is no need to make the setting to pull back the media after printing.


Procedure

① Make the setting to pull back the media after printing, then perform printing of the white or CMYK color data.


* For the LEF series, there is no need to make the setting to pull back the media after printing.

For the printing method using white ink, refer to P. 18, "Printing Using White Ink".


① Click .



② In [Operation Mode], select "Print Only."




③ Turn on the [Return to Origin After Print] option.




When the LEF series is used:

After the printing finishes, the screen below is displayed. Do not change the media and press [ENTER] on the operation panel of the printer to proceed to step ②.




2 Double-click a printing job to open the "Job Setting" window.




2
Printing

3 Select the media type, print quality, and print mode.

① Click .




② For [Media Type], select [Special Effects].



③ Select a [Print Quality].

④ For [Mode], select [GlossVarnish].


- * This mode may be disabled depending on the print quality selected in step 3.
- * The items displayed for [Mode] will vary depending on the model used.
- * The name for [Mode] may have a suffix such as "(v)" or "10p."




④ Set the printer operation.

- * This setting is unnecessary for the LEF series.


① Click .



② In [Operation Mode], select "Print Only."



③ Turn off the [Return to Origin After Print] option.



⑤ Click [OK] to close the "Queue A Properties" window.

This is the end of the print job setting. To start printing, proceed to P. 46, "Starting the Print Operation".

- * Only the settings necessary for the use of the gloss ink and white ink are described in this section. For other settings, refer to the online help provided for VersaWorks.

Matte-finish Printing (White or CMYK Colors > Gloss)

This section describes the printing method that produces a matte finish on the printed item. After performing printing using white and CMYK color data, this method pulls back the media, then performs fill overprinting using gloss ink. This means that the setting must be made to pull back the media after printing the white and CMYK color data.


- * For the LEF series, there is no need to make the setting to pull back the media after printing.

Procedure


- 1 Make the setting to pull back the media after printing, then perform printing of the white or CMYK color data.**

- * **For the LEF series, there is no need to make the setting to pull back the media after printing.**
For the printing method using white ink, refer to P. 18, "Printing Using White Ink".


- 1 Click .**



- 2 In [Operation Mode], select "Print Only."**




- 3 Turn on the [Return to Origin After Print] option.**




When the LEF series is used:

After the printing finishes, the screen below is displayed. Do not change the media and press [ENTER] on the operation panel of the printer to proceed to step **2**.




2 Double-click a printing job to open the "Job Setting" window.




3 Select the media type, print quality, and print mode.

1 Click .





2 For [Media Type], select [Special Effects].




- ③ Select a [Print Quality].
- ④ For [Mode], select [MatteVarnish].
- * This mode may be disabled depending on the print quality selected in step 3.
- * The items displayed for [Mode] will vary depending on the model used.
- * The name for [Mode] may have a suffix such as "(v)" or "10p."




- ④ Set the printer operation.
- * This setting is unnecessary for the LEF series.
- ① Click .



- ② In [Operation Mode], select "Print Only."



- ③ Turn off the [Return to Origin After Print] option.



- ⑤ Click [OK] to close the "Queue A Properties" window.

This is the end of the print job setting. To start printing, proceed to P. 46, "Starting the Print Operation".

- * Only the settings necessary for the use of the gloss ink and white ink are described in this section. For other settings, refer to the online help provided for VersaWorks.

Matte-finish Printing (Single-pass Printing Using CMYK Color and Gloss Inks)

This section describes the printing method that produces a matte finish on the printed item through single-pass printing using CMYK color and gloss inks. Single-pass printing of the CMYK color and gloss ink is enabled only for the matte-finish printing.


Procedure

1 Create data for printing.

☞ P. 9, "Creating Printing Data"


2 Double-click .

The "Queue A Properties" window appears.




3 Select the media type, print quality, and print mode.

1 Click .



2 Select a [Media Type].

Generic with Special Effects	This is the basic setting for the matte-finish printing through single-pass printing using CMYK color and gloss inks.
Generic Distance with Special Effects	This can be selected when you use the LEF-12i, LEF-200, or LEF-300. This setting is suitable when you print on media whose print surface is uneven.



③ Select a [Print Quality].


* The items displayed for [Print Quality] will vary depending on the [Media Type] selected in step 2.

④ For [Mode], select [CMYK -> MatteVarnish].

* This mode may be disabled depending on the print quality selected in step 3.

* The items displayed for [Mode] will vary depending on the model used.


* The name for [Mode] may have a suffix such as "(v)" or "10p."




④ Set the printer operation.

* This setting is unnecessary for the LEF series.

① Click .



② In [Operation Mode], select "Print Only."



③ Turn off the [Return to Origin After Print] option.



⑤ Click [OK] to close the "Queue A Properties" window.

This is the end of the print job setting. To start printing, proceed to P. 46, "Starting the Print Operation".

* Only the settings necessary for the use of the gloss ink are described in this section. For other settings, refer to the online help provided for VersaWorks.

Embossed-finish Printing (White or CMYK Colors > Gloss)

This section describes the printing method that produces an embossed finish by raising the printed surface through fill overprinting using gloss ink. After performing printing using white and CMYK color data, this method pulls back the media, then performs fill overprinting using gloss ink. This means that the setting must be made to pull back the media after printing the white and CMYK color data.

* For the LEF series, there is no need to make the setting to pull back the media after printing.

You use VersaWorks to set the number of fill-overprinting passes using gloss ink. The unit performs matte-finish fill overprinting for the specified number of passes, then performs overprinting one additional time to give the surface a glossy finish. This means that the number of fill-overprint passes using gloss ink is equal to the number set using VersaWorks plus one.


Procedure

1 Make the setting to pull back the media after printing, then perform printing of the white or CMYK color data.


* **For the LEF series, there is no need to make the setting to pull back the media after printing.**

For the printing method using white ink, refer to P. 18, "Printing Using White Ink".


1 Click .



2 In [Operation Mode], select "Print Only."




3 Turn on the [Return to Origin After Print] option.




When the LEF series is used:

After the printing finishes, the screen below is displayed. Do not change the media and press [ENTER] on the operation panel of the printer to proceed to step **2**.




2 Double-click a printing job to open the "Job Setting" window.




2
Printing

3 Select the media type, print quality, and print mode.

1 Click .




2 For [Media Type], select [Special Effects].



③ Select a [Print Quality].


④ For [Mode], select [Embossing].

- * This mode may be disabled depending on the print quality selected in step 3.
- * The items displayed for [Mode] will vary depending on the model used.
- * The name for [Mode] may have a suffix such as "(v)" or "10p."



④ Set the number of overprinting passes.


① Click .



② Select the [Use Custom Settings] check box.

③ Set the number of overprinting passes.


The number of overprint passes for an embossed finish is the specified number of passes plus one. For more information, refer to P. 36, "Specified number of overprinting passes for an embossed finish and ink thickness".




⑤ Set the printer operation.

- * This setting is unnecessary for the LEF series.


① Click .



- ② In [Operation Mode], select “Print Only.”



- ③ Turn off the [Return to Origin After Print] option.



- ⑥ Click [OK] to close the “Queue A Properties” window.

This is the end of the print job setting. To start printing, proceed to P. 46, "Starting the Print Operation".


- * Only the settings necessary for the use of the white ink are described in this section. For other settings, refer to the online help provided for VersaWorks.

Specified number of overprinting passes for an embossed finish and ink thickness

- The number of overprint passes for an embossed finish is the specified number of passes plus one.
- The ink thickness based on the specified number of overprint passes varies according to the type of media used and the printing environment.
- If the print heads rub the printed surface or media jams, review the number of overprint passes, the type of media, and the head position. However, please note that setting a high head position may result in coarse printing.


LEC-330 / 540 or LEJ-640:

(Inks used: Cyan, magenta, yellow, black, gloss, and white)




LEC-330 / 540 or LEJ-640:

(Inks used: Cyan, magenta, yellow, black, gloss, and gloss)




LEF-12i / 200:

(Inks used: Cyan, magenta, yellow, black, gloss, and white)




LEF-300:

(Inks used: Cyan, magenta, yellow, black, gloss, gloss, and white)



LEF-300:

(Inks used: Cyan, magenta, yellow, black, gloss, white, and primer)



Printing Only with Gloss Ink

Gloss finish, matte finish, and embossed finish can also all be printed using only gloss ink.


Procedure

1 Create data for printing.

⇨ P. 9, "Creating Printing Data"


2 Double-click .

The "Queue A Properties" window appears.




3 Select the media type, print quality, and print mode.

1 Click .




2 For [Media Type], select [Special Effects].



- ③ Select a [Print Quality].
- ④ For [Mode], select the print mode.

GlossVarnish	Gloss finish	P. 24, "Gloss-finish Printing (White or CMYK Colors > Gloss)"
MatteVarnish	Matte finish	P. 27, "Matte-finish Printing (White or CMYK Colors > Gloss)" P. 30, "Matte-finish Printing (Single-pass Printing Using CMYK Color and Gloss Inks)"
Embossing	Embossed finish	P. 32, "Embossed-finish Printing (White or CMYK Colors > Gloss)"


- * These modes may be disabled depending on the print quality selected in step 3.
- * The items displayed for [Mode] will vary depending on the model used.
- * The name for [Mode] may have a suffix such as "(v)" or "10p."



④ To use an embossed finish, set the number of overprinting passes.


- * This setting is unnecessary for a gloss finish and a matte finish.

① Click .



- ② Select the [Use Custom Settings] check box.
- ③ Set the number of overprinting passes.


- * The number of overprint passes for an embossed finish is the specified number of passes plus one. For more information, refer to P. 36, "Specified number of overprinting passes for an embossed finish and ink thickness".




5 Set the printer operation.

* This setting is unnecessary for the LEF series.


① Click .



② In [Operation Mode], select "Print Only."



③ Turn off the [Return to Origin After Print] option.



MEMO

See P. 20, "MEMO: When you want to display the side opposite the printed surface by using clear film" when you want to display the side opposite the printed surface by using clear film.

6 Click [OK] to close the "Queue A Properties" window.

This is the end of the print job setting. To start printing, proceed to P. 46, "Starting the Print Operation".

* Only the settings necessary for the use of the white ink are described in this section. For other settings, refer to the online help provided for VersaWorks.

Printing Using Primer

Printing Only with Primer

* "RDG_PRIMER" is usable with VersaWorks Dual only.

This section describes how to perform printing only with primer.


Procedure

1 Create data for printing.

☞ P. 9, "Creating Printing Data"


2 Double-click .

The "Queue A Properties" window appears.




3 Select the media type, print quality, and print mode.


1 Click .





2 For [Media Type], select [Primer].




- ③ Select a [Print Quality].
- ④ For [Mode], select [Primer1] or [Primer2].
- * The items displayed for [Mode] will vary depending on the model used.
- * The name for [Mode] may have a suffix such as "(v)" or "10p."




- ④ Set the printer operation.
- * This setting is unnecessary for the LEF series.
- ① Click .



- ② In [Operation Mode], select "Print Only."



- ③ Turn off the [Return to Origin After Print] option.



MEMO

See P. 20, "MEMO: When you want to display the side opposite the printed surface by using clear film" when you want to display the side opposite the printed surface by using clear film.

- ⑤ Click [OK] to close the "Queue A Properties" window.

This is the end of the print job setting. To start printing, proceed to P. 46, "Starting the Print Operation".

- * Only the settings necessary for the use of the primer are described in this section. For other settings, refer to the online help provided for VersaWorks.

Printing with Primer and CMYK Colors or White in a Single Pass

* "RDG_PRIMER" is usable with VersaWorks Dual only.

This section describes how to print primer data and CMYK color data, or primer data and white data, in a single pass.


Procedure

1 Create data for printing.

☞ P. 9, "Creating Printing Data"


2 Double-click .

The "Queue A Properties" window appears.




3 Select the media type, print quality, and print mode.

1 Click .




2 For [Media Type], select [Generic with Primer].



- ③ Select a [Print Quality].
- ④ For [Mode], select the print mode.

Primer -> CMYK	The primer is overprinted by the CMYK color inks.
Primer -> White	The primer is overprinted by the white ink.


- * The items displayed for [Mode] will vary depending on the model used.
- * The name for [Mode] may have a suffix such as "(v)" or "HD."




4 Set the printer operation.

- * This setting is unnecessary for the LEF series.

① Click .



② In [Operation Mode], select "Print Only."



③ Turn off the [Return to Origin After Print] option.



5 Click [OK] to close the "Queue A Properties" window.

This is the end of the print job setting. To start printing, proceed to P. 46, "Starting the Print Operation".

- * Only the settings necessary for the use of the primer are described in this section. For other settings, refer to the online help provided for VersaWorks.

Starting the Print Operation

Starting the Print Operation


After configuring the print job settings, you can start the print operation.

Procedure

1 Configure the settings for the print job.


- ☞ P. 18, "Printing Using White Ink"
- ☞ P. 24, "Printing Using Gloss Ink"
- ☞ P. 42, "Printing Using Primer"

2 Go to "Job List," click the "Queue A" tab, and drag the printing data to the queue A job list. (If the print job setting has been made in [Queue B], drag and drop the printing data on the job list of [Queue B].)




The contents of the data are displayed in the preview window, and the layout on the media is displayed in the layout window.


- Areas specified to "RDG_WHITE" are displayed with shading in transparent red.
- Areas specified to "RDG_GLOSS" are displayed with shading in transparent blue.
- Areas specified to "RDG_PRIMER" are displayed with shading in transparent green.



MEMO

If the areas specified to "RDG_WHITE," "RDG_GLOSS," or "RDG_PRIMER" are not displayed with shading, any of the settings for [Quality Settings] - [Mode] is incorrect. Check the settings.

- 3** Select the print job in the job list, and then click .
Printing will be started.

**MEMO**

To continue printing similar data, repeat steps **2** and **3**. Also, if you want to modify detailed settings for each job, it will be convenient to perform modifications in the "Job Setting" window (displayed by double-clicking the print job in the job list).

Chapter 3 Advanced

Performing Texture Printing	50
What is Texture Printing?.....	50
Checking the Pattern of Texture Printing	50
Printing Texture Data	52
More Advanced Printing Settings.....	55
Making Printing Settings for Each Job.....	55
Composing CMYK Data and White/Gloss Data with VersaWorks.....	56
Generating Special Color Plates	58
Correcting the Position of Special Color Plates.....	60
Correcting the Size of Special Color Plates.....	62



Performing Texture Printing

What is Texture Printing?

Texture printing is defined as the method of producing texture patterns with gloss ink. This uses the texture patterns provided by the exclusive library to create and output print data.

MEMO

- * “Matte-finish Printing” is recommended for finishing. Detailed representation is difficult with gloss-finish printing and embossed-finish printing.
- * To use Adobe Illustrator for creating the printing data, use version CS5 or later. Using a version of Adobe Illustrator before CS5 to create the printing data may result in texture patterns that do not print well.

Checking the Pattern of Texture Printing

Print a chart that works as a texture print sample and check the texture patterns. Printing a chart allows you to check the texture patterns that can be printed with your printer and your media. By creating print data with the texture pattern you select in this chart, you can print your intended pattern almost perfectly. (Slight pattern differences may result depending on the printer or media content.)


- * To print a chart, use the same media as the one that will actually be used.

Procedure


1 Double-click .

The “Queue A Properties” window appears.

- * Chart output is possible for Queue A only.



- 2 Click , and then set the media type, print quality, and print mode.



Select the media type, print quality, and print mode that will actually be used. For details on how to configure the settings, refer to the following.

- ☞ P. 27, "Matte-finish Printing (White or CMYK Colors > Gloss)"
- ☞ P. 30, "Matte-finish Printing (Single-pass Printing Using CMYK Color and Gloss Inks)"
- ☞ P. 39, "Printing Only with Gloss Ink"


MEMO

When printing a Texture Chart, the [Quality] settings from the [Queue Properties] window are always applied. Because you cannot change the quality settings for the job using the [Job Settings] window after it has been added, be sure to configure the settings in the [Queue Properties] window before performing the following operations.

- 3 Add the texture chart print job to the job list.


- 1 Click [Media] and then [Chart].

The following message appears: "The following job will be printed. Do you want to continue?" Check whether the media in the printer is large enough for the displayed page size.




- 2 Click [OK].

The texture chart print job is added to the job list.



4 Click 

The texture chart from "Roland Texture System Library" is printed.



* Use the printed chart to specify the texture pattern in step 2 of P.52, "Printing Texture Data".

Printing Texture Data

Create printing data for texture printing. The program used to create the printing data is Adobe Illustrator CS6 in this section. For detailed information on drawing methods and how to work with palettes, refer to the documentation or online help for Adobe Illustrator CS6. If you are using another version of Adobe Illustrator, operations may be somewhat different from those explained here.

1. Open the exclusive library.

1 Open the dialog box to use in selecting the library.


① Open the swatch palette menu.

The swatch palette is displayed by going to the menu and selecting [Window], then [Swatches].

② Click [Open Swatch Library].

③ Click [Other Library].

The "Open" (or "Select Library") dialog box appears.




2 Open the exclusive library.

- ① Open the folders in the order of [Computer] → [Local Disk (C:)] → [Program Files] or [Program Files (x86)] → [Roland VersaWorks] or [Roland VersaWorks Dual] → [Swatch] → [Illustrator], and then select “Roland Texture System Library.ai” and “Roland Grapac Bri-o-coat Library.ai.”

* Depending on the settings of your computer, the extension “.ai” might not be shown.


- ② Click [Open].

The exclusive texture libraries “Roland Texture System Library” and “Roland Grapac Bri-o-coat Library” are displayed.



Advanced

When the following screen is displayed, click [Update].



2. Create the illustration and specify the texture pattern you want to use.

1 Create the illustration.

Be sure to draw the illustration in the CMYK mode.


2 Specify the texture pattern you want to use for the area of texture printing.

Check the texture pattern in the chart printed in the procedure of P. 50, "Checking the Pattern of Texture Printing". Since colors and patterns may be slightly different depending on the media, use a chart printed on the same media as the one that will actually be used.

Use gloss ink to print the area where the texture pattern is specified. To use gloss ink for printing other than texture printing, use an exclusive spot color "RDG_GLOSS."

☞ P. 9, "Creating Printing Data"

The name of the texture pattern is displayed above the data in Illustrator. The texture of the displayed image appears rougher than that of the actual print.



3 Use VersaWorks to make settings for "Matte-finish Printing" and print the data.

☞ P. 27, "Matte-finish Printing (White or CMYK Colors > Gloss)"

☞ P. 30, "Matte-finish Printing (Single-pass Printing Using CMYK Color and Gloss Inks)"

☞ P. 39, "Printing Only with Gloss Ink"

IMPORTANT

"Matte-finish Printing" is recommended for finishing. Detailed representation is difficult with gloss-finish printing and embossed-finish printing.

A test pattern is printed.


More Advanced Printing Settings

Making Printing Settings for Each Job

Procedure

Before printing, double-click the print job list.

The “Job Setting” window appears. This window can be used to configure advanced settings for a specific job, including settings that control printer operation and color adjustment.



Description

When outputting numerous jobs consecutively, print settings that vary between jobs can be troublesome. Accordingly, the “Job Setting” window is where you configure the settings for individual jobs before printing. In other words, with this approach, you configure shared basic settings in the “Queue Properties” window and configure the settings for the individual job in the “Job Setting” window. The settings in the “Job Setting” window are reflections of the settings made in the “Queue Properties” window, so job-specific settings such as color adjustment can be configured.

Composing CMYK Data and White/Gloss Data with VersaWorks

When you have print data created for CMYK inks and for white (or gloss) ink separately, you can compose them in VersaWorks to output it as a single job.

To use this feature, the following requirements must be met.

- **The printing-data combination that you can compose is a piece of printing data containing only CMYK colors and one containing only white, or a piece of printing data containing only CMYK colors and one containing only gloss.**
- **The printing data is a TIFF file.**
- **The printing data containing only white or gloss was saved with "Color Mode" of "TIFF Options" set to "Grayscale."**


* In the explanations in this section, Adobe Illustrator CS6 is the program used to create the printing data.

Procedure

1 Prepare a TIFF file containing CMYK colors and a TIFF file containing white (or gloss).


2 Double-click .

The "Queue A Properties" window appears.




3 Select the option for "Special channel configuration" according to the data to be used for printing.

1 Click .





2 Select the option for "Special channel configuration."

- **When using printing data containing white only: Ex1=RDG_WHITE**
- **When using printing data containing gloss only: Ex1=RDG_GLOSS**




4 Set the options to compose the two jobs.

- ① Click .
- ② Select the [Number of Jobs] check box.
- ③ Select "2" for [Number of Jobs].
- ④ Select the [Compose] check box.



⑤ Click [OK].





5 Make the other settings in the "Queue A Properties" window.

* **Single-pass printing of the gloss ink and CMYK color inks is enabled only for the matte-finish printing.**

- ☞ P. 27, "Matte-finish Printing (White or CMYK Colors > Gloss)"
- ☞ P. 30, "Matte-finish Printing (Single-pass Printing Using CMYK Color and Gloss Inks)"

6 Start printing.

- ① Go to "Job List" and click the "Queue A" tab.
- ② Drag the TIFF file containing CMYK colors and TIFF file containing white (or gloss) and drop them into the queue A job list.
Composing is performed automatically.
- ③ Click .



Generating Special Color Plates




This section describes how to generate special color plates (white, gloss, and primer) in VersaWorks Dual. To create special color plates in Illustrator, see P. 9, "Creating Printing Data Using a Spot Color for Special Colors".


* This function is available with VersaWoks Dual only. It is not available with VersaWoks.

You Cannot Generate Special Color Plates for the Following Types of Printing Data.




- Raster format
- Replacement data for variable data printing
- All of [RDG_WHITE], [RDG_GLOSS], and [RDG_PRIMER] are used (when one or two of [RDG_WHITE], [RDG_GLOSS], and [RDG_PRIMER] are used, special color plates can be generated for unused color(s) only).

MEMO

- For the printing data in which any of [RDG_WHITE], [RDG_GLOSS], and [RDG_PRIMER] is used, the following icons are displayed for [Special Items] under [Document Information] in the VersaWorks preview window.
 -  : RDG_WHITE
 -  : RDG_GLOSS
 -  : RDG_PRIMER



Document Information

File Type	PDF File
# of Pages	1
Page Size	216.0 x 303.0 mm
Special Items	  

Procedure

- 1 In the "Job List," double-click the job for which you want to generate special color plates.**
The [Job Settings] window appears.


IMPORTANT

Special color plates are generated in the "Job Settings" window. They cannot be generated in the [Queue Properties] window.


- 2 Configure the printing settings for special color printing.**
Make the settings for printing white, gloss, and primer data in the "Job Settings" window. The setting items are the same as those specified in the "Queue Properties" window.
 - ☞ P. 18, "Printing Using White Ink"
 - ☞ P. 24, "Printing Using Gloss Ink"
 - ☞ P. 42, "Printing Using Primer"





- 3 Click .**

- 4 Select [Generate Special Color Plate].**



- 5 Select [Generated Pattern].**




Original image	Print area	Outside print area	Entire image
	 The plate is generated below the objects.	 The plate is generated in locations where no objects are present.	 The plate is generated for the entire job size.

- 6 Click [OK] to close the [Job Settings] window.**

This is the end of the print job setting. To start printing, proceed to P. 46, "Starting the Print Operation".

Correcting the Position of Special Color Plates

This section explains how to correct the printing position of special plates that have become misaligned, as shown below.



- 1 Media
- 2 Process color
- 3 Special color

* This function is available with VersaWoks Dual only. It is not available with VersaWoks.

1. Perform a test print.

1 Double-click .

The [Queue A Properties] window appears.

MEMO

You can make the same settings also in the [Job Settings] window that is displayed when you double-click printing data in the "Job List."


2 Configure the printing settings for special color printing.

Make the settings for printing white, gloss, and primer data in the "Job Settings" window. The setting items are the same as those specified in the "Queue Properties" window.


- ☞ P. 18, "Printing Using White Ink"
- ☞ P. 24, "Printing Using Gloss Ink"
- ☞ P. 42, "Printing Using Primer"

3 Click .


4 Use the [Special Color] list box under [Special Color Plate Correction] to select the special color ink to correct.



5 Click [Test Print] for [Position Correction].



- 6 Select the [Pattern Settings], and click [OK].
 - **Simple:** Select this to make rough adjustments to position misalignments.
 - **Detailed:** Select this to make detailed adjustments to position misalignments.





A test pattern is printed.

2. Set the correction value.


- 1 Enter the [Horizontal] and [Vertical] correction values.

Select the value on the printed test pattern that results in the least misalignment between A (reference line: black line) and B (special color line). Enter the C values (which represent the [Horizontal] and [Vertical] correction values) written on the test pattern.


- * The test pattern correction values differ for each piece of data. Set the correction values for each piece of data.




Correction Position and Printing Position in the Horizontal Direction



Correction Position and Printing Position in the Vertical Direction




2 Click [OK].



If you have to adjust the size of the special color printing data, proceed to P. 62, "Correcting the Size of Special Color Plates".

Correcting the Size of Special Color Plates

This section explains how to adjust special plates with sizes that have shifted, as shown below. To correct the size, we recommend correcting the position first.



* This function is available with VersaWoks Dual only. It is not available with VersaWoks.

1. Perform a test print.

1 Double-click .

The [Queue A Properties] window appears.

MEMO

You can make the same settings also in the [Job Settings] window that is displayed when you double-click printing data in the "Job List."


2 Configure the printing settings for special color printing.

Make the settings for printing white, gloss, and primer data in the "Job Settings" window. The setting items are the same as those specified in the "Queue Properties" window.


- ☞ P. 18, "Printing Using White Ink"
- ☞ P. 24, "Printing Using Gloss Ink"
- ☞ P. 42, "Printing Using Primer"

3 Click .

4 Use the [Special Color] list box under [Special Color Plate Correction] to select the special color ink to correct.




5 Click [Test Print] for [Size Correction].



6 Select the [Pattern Settings], and click [OK].

- **Simple:** Select this to make rough adjustments to position misalignments.
- **Detailed:** Select this to make detailed adjustments to position misalignments.




A test pattern is printed.

2. Set the correction value.

1 Enter the [Size] correction value.

Select the value on the printed test pattern that results in the least misalignment between A (reference line: black line) and B (special color line). Enter the C values (which represent the [Horizontal] and [Vertical] correction values) written on the test pattern.


* The test pattern correction values differ for each piece of data. Set the correction values for each piece of data.



Correction Value and Printing Position



2 Click [OK].



 **Roland**